

SMARTKEEPER PRO® Line Up

Universal Lock Key 3 works with

- USB Port Lock

USB-B Port Lock

USB-C Port Lock Plus

Link Lock

Link Lock Hub

Link On

Secure Drive

Secure Connector
- Network Port Lock Plus

LAN Cable Lock Plus

Secure LAN Cable Coupler

Network Module Lock 4/8/12P

LAN Cable Link Lock + Dedicated Cable

Fiber Optic LC Cable Lock Dual

Fiber Optic LC Cable Lock Single

Fiber Optic Module Lock Plus
- QSFP Port Lock

Serial Port Lock

DVI Port Lock

Parallel Port Lock

SD Port Lock

CF Port Lock

ODD Lock

DisplayPort Lock
- BNC Port Lock

RF Module Lock (Type N/M)

Lock Key Mini works with

- Mini USB-B Port Lock

Micro USB-B Port Lock

USB-C Port Lock

E-SATA Port Lock
- HDMI Port Lock

Mini DisplayPort Lock

RJ45 Port Lock

No key required

- USB Closing Lock

LAN Cable Grip

PC Lock (Key Type)

PC Lock (Combination)
- LAPTOP DOCK & LOCK

Laptop Lock (Combination)

Laptop Lock Plus (Combination)


Lock Keys

- Universal Lock Key 3
- Lock Key Mini


www.smartkeeperworld.com
Made in Korea

Items working with Universal Lock Key 3


USB Physical Security




Network Physical Security




Other Physical Security




Universal Lock Key 3 How to use




Insert Mode:
Slide the button completely forward and insert/release the key into the lock.



Retrieval Mode:
Slide the button backward to engage the lock for removal and pull out the key.



Storage Mode:
(When don't use) To protect the key header, Slide the button completely backward.




Caution

- Make sure that the key is carefully and fully engaged before removing lock.
- Be careful of sharp key blades. (Put the key blades into storage mode not in use.)

Note

- The manufacturer or vendor is not responsible for any inability to check the serial number.

USB Port Lock
User Guide



SMARTKEEPER
PROFESSIONAL


USB Port Lock

This is a physical cybersecurity device that prevents unauthorized connection to an unused USB port.

Environment




USB Type A Port



Key Slot

Installation

USB Port Lock



1
Insert the USB Port Lock by pressing inward with your fingers.

2
Installation complete.

Please Note:



- The USB Port Lock is designed to work with ports that follow USB port manufacturing standards. Some products in the marketplace may have USB ports that do not follow the manufacturing standard exactly. If a port lock is hard to insert, forcing it to fit may cause damage to the port.

Uninstall (Removal)

USB Port Lock


Please Note:

- During removal, if the lock catches on the surrounding frame, apply gentle pressure in the opposite direction as you pull it out.





When uninstalling, make sure to check and match the direction of the key slot and key as shown. If the insertion direction is not correct, it will not work.

1
Insert the key completely into the key slot.



2
Slide the button backward ② to engage the lock for removal and pull out the key.



3
Slide the button forward to release the lock from the key.

Specification

USB Port Lock	Width x Height x Length(Depth): 12.3 x 4.6 x 10mm(0.48 x 0.18 x 0.39in) Weight: 1g(0.04oz)
---------------	---