SMARTKEEPER PRO® Line Up

Universal Lock Key 3 works with

- USB Port Lock
- USB-B Port Lock
- USB-C Port Lock Plus
- Link Lock
- Link Lock Hub
- Link On
- Secure Drive
- Secure Connector
- Network Port Lock Plus
- LAN Cable Lock Plus
- Secure LAN Cable Coupler
- Network Module Lock 4/8/12P
- LAN Cable Link Lock + Dedicated Cable
- Fiber Optic LC Cable Lock Dual
- Fiber Optic LC Cable Lock Single
- Fiber Optic Module Lock Plus
- QSFP Port Lock
- Serial Port Lock
- DVI Port Lock
- Parallel Port Lock
- SD Port Lock
- CF Port Lock
- ODD Lock
- DisplayPort Lock
- BNC Port Lock
- RF Module Lock (Type N/M)

Lock Key Mini works with

- Mini USB-B Port Lock
- Micro USB-B Port Lock
- USB-C Port Lock
- E-SATA Port Lock
- HDMI Port Lock
- Mini DisplayPort Lock
- RJ11 Port Lock

No key required

- USB Closing Lock
- LAN Cable Grip
- PC Lock (Key Type)
- PC Lock (Combination)
- LAPTOP DOCK & LOCK
- Laptop Lock (Combination)
- Laptop Lock Plus (Combination)

Lock Keys

- Universal Lock Key 3
- Lock Key Mini

www.smartkeeperworld.com

Made in Korea

Items working with **Universal Lock Key 3**

USB Physical Security



Network Physical Security



Other Physical Security



Universal Lock Key 3 How to use

① **Insert Mode:**
Slide the button completely forward and insert/release the key into the lock.

② **Retrieval Mode:**
Slide the button backward to engage the lock for removal and pull out the key.

③ **Storage Mode:**
(When don't use) To protect the key header, Slide the button completely backward.



⚠ Caution

- Make sure that the key is carefully and fully engaged before removing lock.
- Be careful of sharp key blades. (Put the key blades into storage mode not in use.)

? Note

- The manufacturer or vendor is not responsible for any inability to check the serial number.

USB-C Port Lock Plus

User Guide



SMARTKEEPER PROFESSIONAL

USB-C Port Lock Plus

Blocks unused USB-C (type C) port to prevent unauthorized device access.
(⚡ **Thunderbolt is not compatible.)**

ⓘ Environment

USB Type C Port



Specification

USB-C Port Lock Plus	**Width x Height x Length(Depth):** 17.1 x 6.8 x 23.5mm(0.67 x 0.27 x 0.93in) **Weight:** 3.5g(0.12oz)

Installation

USB-C Port Lock Plus



① Insert USB-C Port Lock Plus with the Type-C Lock lettering showing on top.

② Press Lock Button.

③ Installation complete.

⚠ Please Note:

- In some cases, It may not lock properly depending on the internal structure of the USB Type-C port. When inserting a USB-C Port Lock Plus, please ensure that the locking button does not get pressed.

⚠ Caution:



- USB-C Port Lock Plus can be inserted in any direction but Type-C Lock lettering must face same direction as the button on the Universal Lock Key 3.

Uninstall (Removal)

USB-C Port Lock Plus



① Insert the key completely into the key slot.

② Slide the button backward to engage the lock for removal and pull out the key.

③ Slide the button forward to release the USB-C Port Lock Plus from the key.